

Figure 1. Radio Keypad


*Note: The radio keypad does not show the status of the alarm system at all. The left hand "Transmit" LED glows only to show that the keypad is sending a command to the control unit.*

## Using Radio Keypads and Remote Controls.


### Using a Radio Keypad

#### Setting


Secure all your windows and doors. Make sure the system is idle, and that you can hear the warning tones from the sounders.

1. Key in a valid access code (or present your proximity tag).
2. Press either A, B, C or D to set the portion of system that you require. (If you wish to stop setting while the exit tone sounds, then press  key.) The left hand LED glows to show that the keypad is transmitting.
3. Complete setting using the method programmed by the Installer.

#### Unsetting

1. Enter by the designated entry door.
2. Key in a valid access code (or present your proximity tag).
3. Press .

#### Silencing an Alarm

1. Key in a valid access code (or present your proximity tag).
2. Press .

#### Using a Proximity Tag With a Radio Keypad

If you wish to use a Proximity Tag with the radio keypad in place of an access code, then hold the tag up against the proximity tag sensor (see Figure 1).

The keypad glows blue and gives a "click" to show that it has recognised the tag.